

THE CALIBRATING PROCEDURES OF DCA BENCH METER Model : DA-103 (72-7277)

1. Set the range to 200 mA range.
2. Power on.
3. Input the standard DCA 180.0 mA into the the input terminals.
4. Adjust the VR2 until the LCD show 180.0
5. Check other range accuracy if it meet specification.

THE CALIBRATING PROCEDURES OF DCV BENCH METER Model : DV-101 (72-7275)

1. Set the range to 200 mV range.
2. Power on.
3. Input the standard DCV 180.0 mV into the the input terminals.
4. Adjust the VR2 until the LCD show 180.0
5. Check other range accuracy if it meet specification.