SD card real time data recorder PM2.5, %RH, Temp.

AIR QUALITY MONITOR/RECORDER Model : PM-1063SD ISO-9001, CE, IEC1010









The Art of Measurement

PM2.5, %RH, Temp.

AIR QUALITY MONITOR/RECORDER Model : PM-1063SD

FFATLIDES

FB	LATURES
*	Monitoring air pollutant source from dust, petrochemical industry, steel-making plant,
	thermal power plant, restaurant, smoke, burning plants, driving automobiles.
*	The meter is a real-time air quality monitor instrument used to monitor the concentration
	of PM2.5, humidity and temperature in the indoor environment.
*	PM2.5 : 0 to 250 μ g/m^3, Humidity : 5 to 95 %RH, Temperature : 0 to 50 $^{\circ}$ C/ $^{\circ}$ F.
*	PM2.5 time weighted average reading.
*	Data hold, Record(Max,Min)
*	Alarm setting with the beeper sound output.
*	Health index (0-9) detection and alarm.
*	Built-in clock and Calendar, real time data record with SD memory card, sampling time can
	be set from 1 second to 3600 seconds. Just slot the SD card into the computer, all the
	measured values with the time information (year, month, data, hour, minute, second) can
	be downloaded to the Excel directly, then user can make the further data analysis by
	themselves.
*	Manual data record is available, can set the different position(location) No.(1 to 99).
*	SD card capacity : 1GB to 32GB.
*	Dot matrix LCD display.

* Power by UM3/AA(1.5V) X 6 batteries or DC 9V adapter

* RS232/USB PC computer interface

SPECIFICATIONS

SPECIFICATIONS Circuit	Custom single-chip microprocessor LSI circuit.
Display	LCD Size: 2.18 X 2.87" (55.4 X 72.9 mm).
Display	Dot matrix backlit LCD (128 X 240 pixels).
Measurement	* PM2.5(Particulate matter).
ivieasul ethetit	* Humidity.
	* Temperature.
Over-range	* LCD display show " OL "
over range	* The data save into the Micro SD card will show " 999 "
	(overleap the decimal point).
Data Hold	Freezes displayed reading.
Memory Recall	Maximum & Minimum value.
Data Recording	SD memory card (1 GB to 32 GB).
Sampling Time	Approx. 1 second.
Datalogger	 * Real time data logger, saved the data into Micro SD memory card and down load the all the measured value with the time information (year/month/date/ hour/minute/second) down load to the Excel. * Sampling time for data logger : Auto: 2 seconds to 3600 seconds. Manual: Push the data logger button once will save data one time. @ Set the sampling time to 0 second. @ Manual mode, can also select the 1 to 99 position. * When the system detects micro SD format does not match with the Machine that will be mandatory for reformatting to ensure that data records can be normal. * Data error no. : ≤ 0.1% no. of total saved data typically.
Data Output	* Computer interface.
USB/RS232	* Connect the optional USB cable USB-01 will get the USB plug
	* Connect the optional RS232 cable UPCB-02 will get the RS232 plug.
Operating	0 to 50 $^\circ\!{\rm C}$ (32 to 122 $^\circ\!{\rm F}$).
temperature	
Operating	Less than 80% R.H
humidity	
Power Supply	* DC 1.5V, AA (UM-3) Battery X 6 PCs
	(Alkaline or heavy-duty battery).
	* AC to DC 9V power adapter
Power	DC 122 mA approximately.
consumption	Backlight ON approximately DC 142 mA.
Weight	362 g/0.8 LB.
Dimension	164 x 93 x 72 mm (6.5 x 3.7 x 2.8 inch).
Accessories	* Instruction manual
included	* AC to DC 9V power adapter 1 PC
Optional	* SD memory card (4 GB). * USB cable.USB-01.
Accessories	
	* RS232 cable, UPCB-02.
	* Data Acquisition software, SW-U801-WIN, SW-E802.

Electrical SPECIFICATIONS (23 ± 5 ℃)

32.0 °F to 122.0 °F

PM2.5(Particulate matter) Range 0 to 250 µ g/m^3 Resolution Accuracy \pm (10 % reading \pm 20 μ g/m^3) 1 µ g/m^3 Humidity Range 5 % to 95 %RH Accuracy < 70 %RH: ± 3 %RH Resolution 0.1 %RH Temperature Range Resolution Accuracy 0.0 ℃ to 50.0 ℃ 0.1 °C ± 0.8 °C

* Appearance and specifications listed in this brochure are subject to change without notice. 1512-PM1063SD

± 1.5 °F

0.1 °F