

電話廣播中繼器




YTA-850
YTA-851

1. 迴路：經由空置總機局線迴路啟動。
2. 控制功能：AC110V輸出座1組，NC.C.NO接點2組，1000W OUT AC 110V NO.C 接點1組。
3. 其它功能：(1)標準機櫃尺寸可直接按裝或放置於桌上。(2)後板調整方式防止錯誤調整。(3)可前/後奏選擇(YTA-851)。
4. 電源：AC110V 50Hz/60Hz。
5. 輸出：30mv / 10KΩ。
6. 音調：440Hz, 554Hz, 659Hz, 880Hz/880Hz, 659Hz, 554Hz, 440Hz (YTA-851)。
7. 重量：2.2kg。
8. 機器尺寸：430W * 210D * 44H (mm) (附1u L架)。

Telephone Broadcast System

1. Closed-Loop Circuit : Power On via Space PBX Partial Closed- loop Circuit.
2. Control : One AC110V Line Out, Two NC.C.NO Connectors, One 1000W OUT NO.C Connector.
3. Other Functions :
(1) Available table and rack use because of high strength standard 1U design.
(2) Rear Panel Adjustment preventing incorrect adjustment (operation).
(3) Selectable Pre-/Post-announce Chimes(YTA-851).
4. Power Source : AC110V 50Hz/60Hz.
5. Output : 30mv / 10Kohms.
6. Tone Control :
440Hz, 554Hz, 659Hz, 880Hz/880Hz, 659Hz, 554Hz, 440Hz(YTA-851).
7. Weight : 2.2kg.
8. Dimensions : 430W * 210D * 44H(mm)(attached 1u L bracket).



YTA-103

地震預警警報介面機

1. 接受 PC 地震音頻輸入 0dB 啟動。
2. 輸入具備靈敏度調整及全隔離輸入阻抗，可接受 MONO 或 STEREO 聲音輸入，防止 PC 高頻對擴大機設備的干擾。
3. 輸出具備 NC.C.NO 接點 2 組，擴大機啟動接點 1 組，輸出電源座 1 組(受控功能)，手動開啟擴大機開關。
4. 接收氣象局發出信號後，立即觸動擴大機自動開機及地震警報過後自動關機，以避免電力浪費及平時雜音輸入干擾。亦可接受 0.100V 啟動觸發自動開機及地震警報後自動關機。
5. 具備警報指示燈及開機指示燈功能。
6. 連接的擴大機麥克風須具備優先功能。
7. 電氣特性：(1)輸入 Φ3.5mm Jack 及 0.100V 端子。(2)輸出 Φ6.3mm Jack。(3)接點輸出 NC.C.NO *2組，AMP SW *1組，AC OUTLET *1組。(4)音量調整 1 組。(5)靈敏度調整 1 組。(6)警報指示燈 1 組。(7)手動開關帶燈指示 1 組。(8)電源：AC 110V/60Hz。(9)尺寸：430W * 210D * 44H (mm) (附1u L架)。

Earthquake early warning alarm interface unit

1. PC audio input 0dB to accept earthquake started .
2. Enter with sensitivity adjustment and fully isolated input impedance accepts MONO or STEREO Voice input, to prevent the expansion of the high-frequency PC machine equipment interference.
3. Output contacts with NC.C.NO two groups, one group of contacts to expand machine starts , the output power seat Group 1 (control function), manually open the amplifier switches.
4. Meteorological Bureau issued after receiving the signal , the amplifier automatically boot touched immediately after the earthquake and alarm from Shut down automatically to prevent power wastage and normal input noise interference . Kai also acceptable 0.100V Move triggered automatic start and automatic shutdown after the earthquake alarm.
5. With alarm indicator lights and boot function .
6. Connected microphone amplifier must have priority function .
7. Electrical characteristics :
(1)Input Φ3.5mm Jack and 0.100V terminals.
(2)Output Φ6.3mm Jack.
(3)Contact output NC.C.NO*2 group,AMP SW *Group 1,AC OUTLET * Group 1.
(4)A set of volume adjustment .
(5)Sensitivity adjustment group .
(6)Alarm indicator group .
(7)Manual switch light indicates a group .
(8)Power Supply : AC 110V/60Hz.
(9)Dimensions : 430W * 210D * 44H (mm)(attached 1u L bracket).

電話廣播前後奏器(外線)



YTA-851T

1. 模擬電信局48V局線電壓、功能、DTMF解調。
2. 傳送廣播及對講與交換機間信號連接。
3. 可自動產生四音調前奏音響，自動開啟、關閉主機電源。
4. 電源：AC110V/220V 60/50Hz。
5. 輸入：TR 與電話(總機)PBX連線。
6. 音調：440Hz, 554Hz, 659Hz, 880Hz/880Hz, 659Hz, 554Hz, 440Hz。
7. 迴路：經由空置總機局線迴路啟動。
8. 控制功能：AC110V 輸出座 1 組，NC.C.NO 接點 2 組，1000W OUT AC110V NO.C 接點 1 組。
9. 其它功能：(1)可前/後奏選擇。(2)標準機櫃尺寸可直接按裝。(3)後板調整方式防止錯誤調整。
10. 具有三位數密碼設定，可由使用者自行編碼，以防止造成誤撥。
11. 重量：2.3kg。
12. 尺寸：430W * 210D * 44H (mm) (附1u L架)。

Telephone Broadcast System

1. Bureau of Telecommunications 48V analog line voltage, function, DTMF demodulation.
2. Transmitting broadcast signals and switch between the intercom connection.
3. Can automatically generate four tones intro audio, automatically turn on, turn off the system.
4. Power: AC110V/220V 60/50Hz.
5. Enter: TR and Telephone (switchboard) PBX connection.
6. Tones: 440Hz, 554Hz, 659Hz, 880Hz/880Hz, 659Hz, 554Hz, 440Hz.
7. Circuit: Start line loop through the vacant office switchboard.
8. Control functions: AC110V Output Block Group 1, NC.C.NO contact 2 groups 1000W OUT AC110V NO.C contacts a group.
9. Other functions:
(1) pre / post play selection.
(2) standard rack size can be directly loaded.
(3) Adjust the way to prevent errors after adjustment.
10. Has a three-digit password set by the user own coding to prevent accidental dialing cause.
11. Weight: 2.3kg.
12. Dimensions: 430W * 210D * 44H (mm) (attached 1u L bracket).



YTA-853

上下班專用音樂鐘

1. 控制功能：輸出最大控制能力 1000W OUT AC 110V。
2. 迴路：利用卡鐘或自動定時設備輸出啟動。
3. 其它功能：(1)標準機櫃尺寸可直接按裝或放置於桌上。(2)可改接為接點啟動方式。
4. 電源：AC110V 50Hz/60Hz。
5. 輸出：A 曲 / B 曲 (各可 15 種曲目選擇)。
6. 手動觸動方式：A 曲約 5 秒。
7. 重量：2.3kg。
8. 機器尺寸：430W * 210D * 44H (mm) (附1u L架)。

Auto Bell System

1. Control Functions : Max. Control 1000W OUT AC110V.
2. Closed Loop : Using Clock or Auto Timer Facility to Output Power ON.
3. Other Functions :
(1) Available table and rack use because of high strength standard 1U design.
(2) Modified into Connector Power On (style).
4. Power Source : AC110V 50Hz/60Hz.
5. Output : Selectable Chime A & Chime B.
6. Manual Operation : 5 Seconds for Chime A.
7. Weight : 2.3kg.
8. Dimensions : 430W*210D*44H(mm)(attached 1u L bracket).